#### **RECONDITIONING MANUAL**



Rebel RA&TW To secure that the walking-aid will function safely for the user, once per year review of the walking-aid should be done. Therefore is the following interventions recommended. ☐ Cleaning When cleaning the walker it is recommended machine washing, 60 degrees for 10 minutes. When using a pressure washer, do not wash directly to the bearings. In addition to machine washing, regular cleaning with a mild cleanser is recommended. **Note!** Do NOT use thinner, petrol or other solvents. ☐ Post treatment After washing, all connections, tight spaces and drainage holes should be blown dry and sprayed with thin oil. If degreaser is used, should the moving parts be lubricated. ☐ The Paint Control damages to the paint. To prevent corrosion, improve scratches. Touch-up paint (art nr: F2) can be ordered from Human Care HC AB. ☐ Pipe frame Control weldings and screw attaches. If the corrosion is extensive shall the rollator be replaced. Handle Must be fixed. Make sure the handle pipes can be pushed down to the chassis.



☐ Brakes

Control that both brakes and parkingbrakes are working. Wires should be intact and stapped to the chassis.

☐ Wing nut

Control function.

Reflectors

Make sure the reflectors are still there and visible.

☐ CE and MD-marking

Make sure that the CE and MD marking are still there and readable.

Wheels

Make sure the wheels are not worn-out and are spinning easily without noice.

Lubrication

Gatebushings and hinges should be working without any noice. Lubricate when needed.

Front forks

Make sure that attachments and bearings does not fit loosely and are spinning easily. Check that the set screw screw above the front fork is fully screwed in.

☐ Folding mechanism

Should be intact and the locking should function.

☐ Seat

Make sure that the seat is kept in place and the nuts are tightened.

☐ Stability

Control that all wheels are steadily on the ground and that there are no chassis distortion.

☐ Test driving

Make a final control by test driving.



### **RECONDITIONING MANUAL**

#### Note!

Recondition must be done by a person how has good knowledge about how the job should be performed. An incorrect performed recondition could result an accident/incident. Don't hesitate to contact your retailer if questions come up.

When exchanging parts of the rollator, use only Human Care parts to ensure continued CE-validation.

When disassembling of a wheel, the wheel nut and pin bolt must be replaced since they contain a self-locking that will be destroyed when disassembling.

If the corrosion is more than a film of rust the rollator shall be discarded and return for recycling.

#### Intended use

The RA-rollator/trolley walker should only be used as support whilst walking. Do not alter the RA-rollator/trolley walker yourself.

Product number:
Owner:
Notes:
Attended by:
Place and date:

# **Spareparts list**

No	Designation	Quantity	Art. no	Other information
	Wheel kit	4	89015	Pin bolt and wheel nut must be
1	Complete wheel	4		exchanged when disassemble the
2	Wheel nut	4		wheel.
3	Pin bolt	4		
	Pin bolt & Wheel nut	4	89032	Pin bolt and wheel nut must be
2	Wheel nut	4		exchanged when disassemble.
3	Pin bolt	4		
	Front fork kit	2	89099	From 200907
	Front fork	2		Pin bolt and wheel nut must be
	Bearing	4		exchanged when disassembling
2	Wheel nut	2		the fork.
3	Pin bolt	2		
	Cover cap	2		Front fork kit nr: 89025, only for
	Screw M12x56	2		Rebel rollators produced before
	Screw M6x7	2		April 2024.
	Washer	2		'
	Locking washer	2		
	Brake kit	2	89095	Pin bolt and wheel nut must be
4	Brake inner part	2		exchanged when disassembling
5	Brake outer part	2		the brake.
6	Pop nut	2		
7	Wear washer	2		
8	Screw M6x6	2		
9	Washer	2		
10	Adjustment screw	2		
11	Spring	2		
12	Screw M6x16	2		
2	Wheel nut	2		
3	Pin bolt	2		
7	Wear washer	2	10-004	Wear washer turns when worn.
13	Handle brake complete	2	10650	
14	Handle	2	00020	
	RA			
15	RA-Cushion	2	20-054	
	RA-Bracket compl right	1	100-002H	
16	RA-Bracket compl left	l i	100-002V	

## **RECONDITIONING MANUAL**

No	Designation	Quantity	Art. no	Other information
	TW			
18	Walking table cushion	I	20-053	
19	Cushion screw	4	81800	
20	Bracket compl right	I	100-001H	
21	Bracket compl left	I	100-001V	
22	Teleskopic tube	2	20-010K	Rebel 67 RA/TW Low
22	Teleskopic tube	2	20-010L	Rebel 67 RA/TW Normal
22	Teleskopic tube	2	20-011K	Rebel 72 RA/TW Low
22	Teleskopic tube	2	20-011L	Rebel 72 RA/TW Normal
	Wing nut complete	2	50937	Lubricate the wing nut when needed.
23	Wing nut	2		
24	Screw	2		
25	Washer	2		
26	Wire housing	2	00011	Rebel 67/72 RA/TW Low
26	Wire housing	2	00012	Rebel 67/72 RA/TW Normal
26	Wire	2	00005	Rebel 67/72 RA/TW Low/Normal
	Wire lock	2	10-017	
	Wire end	2	00205	
	Seat kit	I	89020	
27	Seat	I		
28	Gate lock	I		
29	Fold loop	I		
30	Screw M6x20	2		
31	Screw to gate lock	4		
	Seat complete	I	89070	
27	Seat	I		
30	Screw M6x20	2		
	Tube protection	I	50949	
29	Fold loop	I	10-009	
l .	Gate lock kit	I	10-018	
28	Gate lock	I		
31	Screw to gate lock	4		
29	Fold loop	I		
32	Gate upper complete	I	20-047MB	Rebel RA/TW 67
32	Gate upper complete	I	20-047B	Rebel RA/TW 72
32	Gate upper complete -seat	I	20-037MB	Rebel RA/TW 67
32	Gate upper complete -seat	I	20-037B	Rebel RA/TW 72
	Reflex	2	00028	
	Touch-up paint		F2	

